

96" HIGH UTILITY INSTALL INSTRUCTIONS

- Actual Cabinet dimensions (without toe kick platform) will be 91 ½" high
- When installing, place the utility cabinet on top of the toe kick platform with 4" of the cabinet overhanging the platform
- Fasten the cabinet to the platform by drilling screws from the inside of the cabinet bottom into the cross pieces of the platform

TOE KICK PLATFORM

